



CATALOG OF USERS INTERFACES EXAMPLES (HMI):


001




002




003



004



005



006




007



008







011




012



013




014



015




016



017



018




019




020




021




022




023



024



025





BEEPT OOLKIT
BEEPTEC ENGINEERING ©

START



	TIME OF CYCLE	ON OFF
PA 1	01:00:00	1
PA 2	01:00:00	1
PA 3	01:00:00	1
PA 4	01:00:00	1
PA 5	01:00:00	1
PA 6	01:00:00	1
PA 7	01:00:00	1
PA 8	01:00:00	1
PA 9	01:00:00	1
PA 10	01:00:00	1
PA 11	01:00:00	1
PA 12	01:00:00	1
PA 13	01:00:00	1
PA 14	01:00:00	1
PA 15	01:00:00	1

	TIME OF CYCLE	ON OFF
PB 0	01:00:00	1
PB 1	01:00:00	1
PB 2	01:00:00	1
PB 3	01:00:00	1
PB 4	01:00:00	1
PB 5	01:00:00	1
PB 6	01:00:00	1
PB 7	01:00:00	1
OFF	01:00:00	1

PAUSE

Save **Read**